


# T 01 FEEDER PARTS



PART #	DESCRIPTION	REQ
T01 100	FRONT DISK	1
T01 101	REAR DISK	1
T01 102	MOUNTING BRACKET	1
T01 103	HAND KNOB	1
T01 104	MOVEMENT ASSEMBLY	1
T01 104A	MOVEMENT STOP PIN	1
T01 105	UPPER END PLATE	1
T01 106	LONG HOUSING	1
T01 107	UPPER PISTON	1
T01 108	SPRING*	1
T01 109	PRESSURE PAD	1
T01 110	DRIVE BEARING*	3
T01 111	DRIVE PIN*	3
T01 112	SPRING RETAINER*	3
T01 113	SPACER	6
T01 114	SHORT HOUSING	2
T01 115	LOWER PISTON	2
T01 116	THRUST BEARING*	2
T01 117	THRUST RACE*	4
T01 118	ADJUSTMENT PLATE	8
T01 119	LOWER END PLATE	2
T01 120	HEX BOLT*	12
T01 121	GREASE NIPPLE*	6
T01 122	LOWER HEX BOLT*	4
T01 123	UPPER HEX BOLT*	2
T01 124	FLAT WASHER*	6
T01 125	LOCK WASHER*	6
T01 126	ACORN NUT*	6
T01 127	BLACK PLASTIC KNOB*	1
T01 128	TENSION SPRING*	1
T01 129	TENSION SPRING SCREW*	1